


#### www.weiderfitness.com

Model No. WEBE1012.0 Serial No.

Write the serial number in the space above for reference.



### **QUESTIONS?**

If you have questions, or if parts are damaged or missing, **DO NOT CONTACT THE STORE**; please contact Customer Care.

IMPORTANT: Please register this product (see the limited warranty on the back cover of this manual) before contacting Customer Care.

CALL TOLL-FREE:

1-877-992-5999


Mon.-Fri., 6 a.m.-6 p.m. MT Sat. 8 a.m.-4 p.m. MT

ON THE WEB: www.weiderservice.com

## **ACAUTION**

Read all precautions and instructions in this manual before using this equipment. Keep this manual for future reference.

# **USER'S MANUAL**






## **TABLE OF CONTENTS**

WARNING DECAL PLACEMENT	2
IMPORTANT PRECAUTIONS	3
BEFORE YOU BEGIN	
ASSEMBLY	
EXERCISE GUIDELINES	
PART LIST/EXPLODED DRAWING	
ORDERING REPLACEMENT PARTS	Back Cove
I IMITED WARRANTY	Back Cover

## **WARNING DECAL PLACEMENT**



## IMPORTANT PRECAUTIONS

**ANNING:** To reduce the risk of serious injury, read all important precautions and instructions in this manual and all warnings on your weight bench before using your weight bench. ICON assumes no responsibility for personal injury or property damage sustained by or through the use of this product.

- It is the responsibility of the owner to ensure that all users of the weight bench are adequately informed of all precautions.
- Before beginning any exercise program, consult your physician. This is especially important for persons over age 35 or persons with pre-existing health problems.
- Use the weight bench only as described in this manual.
- The weight bench is intended for home use only. Do not use the weight bench in a commercial, rental, or institutional setting.
- Keep the weight bench indoors, away from moisture and dust. Do not put the weight bench in a garage or covered patio, or near water.
- Place the weight bench on a level surface, with a mat beneath it to protect the floor or carpet. Make sure that there is enough

- clearance around the weight bench to mount, dismount, and use the weight bench.
- 7. Inspect and properly tighten all parts regularly. Replace any worn parts immediately.
- 8. Keep children under age 12 and pets away from the weight bench at all times.
- The weight bench is designed to support a maximum user weight of 250 lbs. (113 kg) and a maximum total weight of 360 lbs. (163 kg). Note: The weight bench does not include weights.
- Wear appropriate clothes while exercising.
  Always wear athletic shoes for foot protection while exercising.
- 11. Over exercising may result in serious injury or death. If you feel faint or if you experience pain while exercising, stop immediately and cool down.

## **BEFORE YOU BEGIN**

Thank you for selecting the compact WEIDER® SA 10-4 weight bench. The SA 10-4 weight bench is designed to be used with your own weights to develop the major muscles of your upper body.

For your benefit, read this manual carefully before using the weight bench. If you have questions after

reading this manual, please see the front cover of this manual. To help us assist you, note the product model number and serial number before contacting us. The model number and the location of the serial number decal are shown on the front cover of this manual.

### **ASSEMBLY**

- Place all parts in a cleared area and remove the packing materials. Do not dispose of the packing materials until you finish all assembly steps.
- To identify small parts, see the drawings in the box below. The number in parentheses below each drawing is the key number of the part, from the PART LIST near the end of this manual. The number following the key number is the quantity needed for assembly. Note: If a part is not in the hardware kit, check to see if it has been preassembled. Extra parts may be included.
- In addition to the included tool(s), assembly requires the following tool(s):


one Phillips screwdriver



two adjustable wrenches




Assembly may be easier if you have a set of wrenches. To avoid damaging parts, do not use power tools.



1. Orient a Base (3) as shown.


Attach the Base (3) to one of the Uprights (2) with two M10 x 50mm Bolts (7), four M10 Washers (10), and two M10 Locknuts (12).

Attach the other Base (3) to the other Upright (2) in the same way.




 Attach the Frame (1) to one of the Uprights (2) with two M10 x 20mm Bolts (8), two M10 Washers (10), and two M10 Locknuts (12).

Attach the Frame (1) to the other Upright (2) in the same way.



3. Attach the Bench (4) to the Frame (1) with four M8 x 20mm Screws (9) and four M8 Washers (11); start all four Screws, and then tighten them.

Make sure that all parts are properly tightened before you use the weight bench.



## **EXERCISE GUIDELINES**

#### FOUR TYPES OF STRENGTH WORKOUTS

Note: A "repetition" is one complete cycle of an exercise, such as one sit-up. A "set" is a series of repetitions.

**Muscle Building**—Work your muscles near their maximum capacity and progressively increase the intensity of your exercise. Adjust the intensity level of an individual exercise as follows:

- · Change the amount of resistance used.
- · Change the number of repetitions or sets performed.

Use your own judgment to determine the amount of resistance that is right for you. Begin with 3 sets of 8 repetitions for each exercise you perform. Rest for 3 minutes after each set. When you can complete 3 sets of 12 repetitions without difficulty, increase the amount of resistance.

**Toning**—Tone your muscles by working them to a moderate percentage of their capacity. Select a moderate amount of resistance and increase the number of repetitions in each set. Complete as many sets of 15 to 20 repetitions as possible without discomfort. Rest for 1 minute after each set. Work your muscles by completing more sets rather than by using high amounts of resistance.

**Weight Loss**—To lose weight, use a low amount of resistance and increase the number of repetitions in each set. Exercise for 20 to 30 minutes, resting for a maximum of 30 seconds between sets.

**Cross Training**—Combine strength training and aerobic exercise by following this type of program:

- Strength training workouts on Monday, Wednesday, and Friday.
- 20 to 30 minutes of aerobic exercise on Tuesday and Thursday.
- One full day of rest each week to give your body time to regenerate.

#### **WORKOUT GUIDELINES**

Familiarize yourself with the equipment and learn the proper form for each exercise. Use your own judgment

to determine the appropriate length of time for each workout, and the numbers of repetitions and sets to complete. Progress at your own pace and be sensitive to your body's signals. Follow each workout with at least one day of rest.

**Warming Up**—Start with 5 to 10 minutes of stretching and light exercise. A warm-up increases your body temperature, heart rate, and circulation in preparation for exercise.

**Working Out**—Include 6 to 10 different exercises in each workout. Select exercises for every major muscle group, emphasizing areas that you want to develop. To give balance and variety to your workouts, vary the exercises from workout to workout.

**Cooling Down**—Finish with 5 to 10 minutes of stretching. Stretching increases the flexibility of your muscles and helps to prevent post-exercise problems.

#### **EXERCISE FORM**

Move through the full range of motion for each exercise and move only the appropriate parts of the body. Perform the repetitions in each set smoothly and without pausing. The exertion stage of each repetition should last about half as long as the return stage. Exhale during the exertion stage of each repetition and inhale during the return stroke. Never hold your breath.

Rest for a short period of time after each set:

- Muscle Building—Rest for three minutes after each set.
- Toning—Rest for one minute after each set.
- · Weight Loss—Rest for 30 seconds after each set.


#### **STAYING MOTIVATED**

For motivation, keep a record of each workout. Write the date, the exercises performed, the resistance used, and the numbers of sets and repetitions completed. Record your weight and key body measurements once a month. To achieve good results, make exercise a regular and enjoyable part of your life.

# PART LIST/EXPLODED DRAWING

Key No.	Qty.	Description	Key No. Qty.	Description
1	1	Frame	8 4	M10 x 20mm Bolt
2	2	Upright	9 4	M8 x 20mm Screw
3	2	Base	10 12	M10 Washer
4	1	Bench	11 4	M8 Washer
5	4	Base Cap	12 8	M10 Locknut
6	2	Frame Cap	• –	User's Manual
7	1	M10 v 50mm Bolt		

Note: Specifications are subject to change without notice. For information about ordering replacement parts, see the back cover of this manual. \*These parts are not illustrated.



### ORDERING REPLACEMENT PARTS

To order replacement parts, please see the front cover of this manual. To help us assist you, be prepared to provide the following information when contacting us:

- the model number and serial number of the product (see the front cover of this manual)
- the name of the product (see the front cover of this manual)
- the key number and description of the replacement part(s) (see the PART LIST and the EXPLODED DRAWING near the end of this manual)

#### LIMITED WARRANTY

IMPORTANT: You must register this product within 30 days of the purchase date to avoid added fees for service needed under warranty. Go to www.weiderservice.com/registration.

ICON Health & Fitness, Inc. (ICON) warrants this product to be free from defects in workmanship and material, under normal use and service conditions. Parts and labor are warranted for ninety (90) days from the date of purchase.

This warranty extends only to the original purchaser (customer). ICON's obligation under this warranty is limited to repairing or replacing, at ICON's option, the product through one of its authorized service centers. All repairs for which warranty claims are made must be preauthorized by ICON. If the product is shipped to a service center, freight charges to and from the service center will be the customer's responsibility. If replacement parts are shipped while the product is under warranty, the customer will be responsible for a minimal handling charge. For in-home service, the customer will be responsible for a minimal trip charge. This warranty does not extend to freight damage to the product. This warranty will automatically be voided if the product is used as a store display model, if the product is purchased or transported outside the USA, if all instructions in this manual are not followed, if the product is abused or improperly or abnormally used, or if the product is used for commercial or rental purposes. No other warranty beyond that specifically set forth above is authorized by ICON.

ICON is not responsible or liable for indirect, special, or consequential damages arising out of or in connection with the use or performance of the product; damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyment or use, or costs of removal or installation; or other consequential damages of any kind. Some states do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to the customer.

The warranty extended hereunder is in lieu of any and all other warranties, and any implied warranties of merchantability or fitness for a particular purpose are limited in their scope and duration to the terms set forth herein. Some states do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to the customer.

This warranty provides specific legal rights; the customer may have other rights that vary from state to state.

ICON Health & Fitness, Inc., 1500 S. 1000 W., Logan, UT 84321-9813